



BSA TROOP 137 2010 CHRISTMAS TREE SALE

STARBUCKS ELECTRICAL LAYOUT

POWER SOURCES

Familiarize yourself with the diagram below. Four outlets are located on the street side of the brick wall. Connect the yellow extension cord that powers the tent and chain saw to the outlet closest to the tent. Using the other extension cords, connect halogen lamps from the trailer (they may still be in the flower beds around the brick wall) to each of the other three outlets. These outlets are on separate circuits with little chance for overloading. One set of halogen lights shines on each side of the sale sign in the middle of the brick wall. Some halogen lights will rest on top of the wall and shine towards the parking lot. Some should be on towers: 1 set in the parking lot near the trailer and 1 set near the tent, shining toward the street.

LAYOUT

